



# CEILING SHUTTERS

## STANDARD CEILING SHUTTER

MODEL NUMBER	FAN Size	Outside Dimensions	Inside Dimensions	Ship Wt.
<b>AS10</b>	24"	26" x 26"	24" x 24"	6
<b>AS13</b>	30"	32" x 38"	30" x 36"	9
<b>AS16</b>	36"	34" x 45"	32" x 43"	12
<b>AS18</b>	42"	36" x 48"	34" x 46"	14
<b>AS26</b>	48"	38" x 58"	36" x 56"	16



## NO-CUT JOIST CEILING SHUTTER

MODEL NUMBER	FAN Size	Outside Dimensions	Inside Dimensions	Ship Wt.
<b>CSS-24</b>	24"	24" x 32"	22" x 30"	9
<b>CSS-30</b>	30"	32" x 35"	30" x 33"	10
<b>CSS-36</b>	36"	32" x 43"	30" x 41"	11
<b>CSS-42</b>	42"	38" x 49"	36" x 47"	15

Note: CSS Shutter not available for 48" fan size

### OPENING SIZES

MODEL NUMBER	Blade Dia	Opening Size
<b>CSS-24</b>	24"	10 1/4" x 30 1/4"
<b>CSS-30</b>	30"	14 1/4" x 33 1/4"
<b>CSS-36</b>	36"	14 1/4" x 41 1/4"
<b>CSS-42</b>	42"	17 1/4" x 47 3/4"

Note: CSS-42 for 24" o.c. joist only

Installs centered on a joist with 16" or 24" centers.  
Cut two openings, one on each side of the center joist.

Well-established Industry standards recommend using a fan that will change all the air in your house once every 1-1/2 to 2 minutes (in cooler climates, once every 2 to 3 minutes).

Whole house fans are designed to change the air in your home by drawing in cooler outside fresh air and exhausting the warmer inside air.

